


STORM
LONDON

CHRONO TERRAIN
Limited Edition



- Dial 1: Main time Seconds indicator.
- Dial 2: Hours indicator for STOPWATCH
- Dial 3: Minute indicator for STOPWATCH
- SSH: Stopwatch Second Hand only.

FUNCTIONS AND FEATURES

- STOPWATCH. (Measure up to 12 hours.)
- DATE.
- LUMINOUS HANDS AND NUMBERS.
- DUAL TIME.
- WATER RESISTANT 50M/5ATM

SETTING THE TIME AND DATE

TIME

Pull the crown out to position 2.
Turn the crown anticlockwise to set to desired time. Please note that the date will change at 12:00am Midnight.

DATE

Press the crown in to position 1.
Turn the crown anticlockwise to set the date.
Press the crown in to position 0 to complete.

USING THE STOPWATCH

Press button B to START/STOP
Press button A to RESET Stopwatch second hand and Dials 2 and 3.

RESETTING THE STOPWATCH

If the Stopwatch second hand does not line up with the 12 o'clock marker, Pull the crown out to position 2 and press BUTTON B to advance the second hand around the dial to reset back to the 12 o'clock position.



NV07